

QUICKDRAW 300

TRIPLE-ACTION VAPORIZER

With three material-specific cartridges, the QuickDraw 300 smart-heats dry herb, liquid, and extract to the precise temperatures at which each medium produces rich, flavorful vapor.



QuickDraw

300

TRIPLE-ACTION VAPORIZER

USER
GUIDE



WWW.HOLDYOURFIRE.COM

HOLD YOUR FIRE™

PREPPING THE QUICKDRAW 300



- 1 Unpack & fully charge device.



- 2 Unscrew cartridge mouthpiece and fill chamber.



- 3 Replace mouthpiece & slide cartridge into vaporizer chassis.



- 4 Press heating button 3 times rapidly to unlock device for use.

FAST CHARGING

To fully charge the QuickDraw 300 before use, attach the magnetic charger tip to the end of the device & insert the cord into a USB port. Both the LED Ring and Indicator Ring will flash white to signal charging. The Indicator Ring will turn red intermittently while charging, and will turn green when the device is fully charged.


- LED Ring & Indicator Ring will flash white twice to signal a recharge is needed.
- The QuickDraw 300 is specifically designed to allow use while charging.

UNLOCKING THE QUICKDRAW 300

The QuickDraw 300 is equipped with a 3-click battery lock to prevent unintentional activation. Pressing the heating button 3 times rapidly will unlock the device for use, which the Indicator Ring will signify by flashing white.

To lock the QuickDraw 300, press the heating button rapidly in the same fashion. The Indicator Ring will flash red to signal the device is locked.

CARTRIDGE PREPARATION & USE




DRY

- Remove mouthpiece from cartridge body
- Place shredded dry herb loosely in chamber, below white chamber wall
- Replace mouthpiece & slide cartridge into vaporizer chassis
- Unlock QuickDraw 300
- Press & hold button for 3 seconds to begin precision-heating use
- QuickDraw 300's LED Ring will glow green when ready for use
- Draw from mouthpiece, without pressing or holding button
- Press and hold button for 3 seconds to deactivate
- QuickDraw 300 will auto-deactivate after 2 minutes to prevent undesired use



EXTRACT

- Unscrew mouthpiece from cartridge body
- Place extract in chamber, below overflow line
- Reattach mouthpiece & slide cartridge into vaporizer chassis
- Unlock QuickDraw 300
- Press & hold button as you draw
- QuickDraw 300 will auto-deactivate after 30 seconds to prevent undesired use



LIQUID

- Unscrew mouthpiece from cartridge body
- Fill chamber with liquid, below overflow line
- While filling, hold cartridge at an angle to prevent liquid from entering central vapor path
- Reattach mouthpiece & slide cartridge into vaporizer chassis
- Unlock QuickDraw 300
- Press & hold button as you draw
- If held for longer than 10 seconds, QuickDraw 300's LED Ring will flash before device shuts down, preventing undesired use

CARTRIDGE MAINTENANCE

The QuickDraw 300 comes equipped with a kit of cleaning and maintenance tools that should be used regularly to clear the device and its cartridges of debris. Regular cleaning will ensure long cartridge life.



PLEASE CONTACT QUICKDRAW'S
EXPERT SUPPORT TEAM WITH ANY
QUESTIONS OR CONCERNS.
1 (800) 591-3613

Visit HoldYourFire.com for
product news & updates or to
view QuickDraw's entire line of
vaporizers & accessories.

QuickDraw

©2014 QD Products, LLC.
QuickDraw, and the QuickDraw
logo, are trademarks of QD
Products, LLC.
All rights reserved.